



**Slow Willie** is a dry, powdered concrete delay set product conveniently packaged in easy-to-use 1 lb. bags. It's easily mixed in with concrete during the placing operation giving you greater control. This must-have power concrete retarder saves you money and time. Delaying the setting time allows the operator time to reach proper clean-out locations. This pre-packaged delay set works well with any mix and will not affect structural concrete strength. Use one bag to delay one yard of concrete for up to 3 hours.

#### Features & Benefits:

- **SIMPLE:** No pre-mixing required
- **DELAYS SET:** Delay concrete set for up to three hours
- **SAFE:** No long-term impact on concrete
- **ECONOMICAL:** Minimal expense
- **CHEAP INSURANCE:** Alleviate thousands of dollars in downtime and broken equipment
- **EQUIPMENT-FRIENDLY:** Reduce wear and tear on equipment
- **LABOR SAVER:** Minimize time spent removing hardened concrete
- **INCREASED FLEXIBILITY:** Allow time to reach proper clean-out location

## Slow Willie

Available sizes	
Box (20 sachets)	16 oz. / 454 gr.
Pail (20 sachets)	16 oz. / 454 gr.

### Instructions

#### Step 1.

Add a one pound bag into the mix for each yard of concrete to be delayed for up to three hours. The following quantities are based on a standard concrete hopper on the pump and 5 inch lines: Instructions

#### BOOMS

Booms 32 meters and below - one bag.  
Booms larger than 32 meters - two bags.

#### LINE PUMPS

For large lines (5 inches) use one bag for each 100 feet.  
For small lines (less than 5 inches) use one bag for each 200 feet.

#### Step 2.

Agitate at high speed for five minutes.

#### Step 3. Mix:

If there is concrete in the pump system, please tip hose over hopper and re-circulate so that Slow Willie is completely mixed with all concrete in system and hopper.

#### Step 4. Adjustments:

If Slow Willie treated concrete will be used:

- Sooner than planned, add fresh concrete or concrete accelerators.
- Later than planned and has not returned to its original slump, simply add more Slow Willie.



Scan For Disclaimer &  
Full Instruction Page