

Products Warranty - Australia

For warranty details see our website:

<https://www.faucetstrommen.com.au/warranty/>

Installation Guide **IG 027**

Release Date: 13.12.22

Cascade Bathroom Accessories



Suits Models:

40000, 40010, 40020, 40030, 40040, 40050, 40060, 40070, 40080, 40090, 40091, 40100, 40110, 40120, 40130, 40140, 40150

Important requirements:



Must be fitted in accordance with AS/NZS 3500 by qualified plumber



Mains 500kpa regulator must be fitted



Maximum hot water temp. 65°C



Water lines must be flushed prior to connection



Only clean municipal water supply. No bore, dam or hard water without filtration & treatment

Cleaning

Clean only with a soft microfiber or similar cloth and warm clean water. Ensure that the cloth is clean and free of any grit or chemical. Dry tap off with a soft clean cloth. Ensure that your tap is not subject to any chemicals, building grit or any type of abrasive or polish. For care of special finishes please visit our website.

Installation:

1. Choose a suitable location for your bathroom accessories and draw a horizontal and vertical pencil line on the wall to mark the centre position.
2. For Towel Rails, note that the towel rail specified length is the centre to centre distance between the 2 mount plates.
3. Hold the mount plate in place centrally over the marked cross with the mount holes oriented horizontally.
4. Trace the mount holes through the plate onto the wall with a pencil. Note adjustment in plate holes.
5. For masonry installation, drill three 7mm holes and insert the plastic wall plugs
6. For timber wall construction, drill three 6mm holes through the tiles/wall board only and drill 2mm pilot holes into the timber.
7. Screw into position with the stainless steel screws provided. Ensure that the mount plate is fitted level and oriented correctly with the indentation at the bottom (this is where the grub screw on the bracket fastens into the mount plate).
8. Hang dress rings over each mount plate.
9. Bring accessory into position over mount plates. While gently pressing accessory against wall, slide dress rings up behind the flange section.
10. Place the bathroom accessory into position over the spigot of the mount plate.
11. Tighten into position with a grub screw into the fixing hole underneath the accessory and fasten in place with the Allen key provided.

