

#### Products Warranty - Australia

Faucet Australia Pty Limited (ABN 83 683 523 321) warrants its products to the original owner as per the periods in the table below. This For warranty details see our website:

<https://www.faucetstrommen.com.au/warranty/>

# Installation Guide **IG 016**

Release Date: 13.12.22

## Lug Fix Bathroom Accessories



#### Suits Models:

30700 30701 30702 30703 30704 30705 30706 30707 30708 30709 30710 30711  
30714 30716 30717 30718 30970 30971 30972 30973 30974 30975 30976 30977  
30978 30979 30980 30981 30982 30984 30985 30987 35150 35151 35152 35153  
35154 35155 35156 35157 35158 35160 35161 35162 35165  
35167 35168 35169

#### Cleaning

Clean only with a soft microfiber or similar cloth and warm clean water. Ensure that the cloth is clean and free of any grit or chemical. Dry tap off with a soft clean cloth. Ensure that your tap is not subject to any chemicals, building grit or any type of abrasive or polish. For care of special finishes please visit our website.

**Fit Off:**

1. Choose a suitable location for your bathroom accessories and draw a horizontal and vertical pencil line on the wall to mark the centre position.
2. For Towel Rails, note that the towel rail specified length is the centre to centre distance between the 2 mount plates.
3. For Glass shelf the brackets are normally spaced at 300mm, although this is approximate.
4. Hold the mount plate in place centrally over the marked cross with the mount holes oriented horizontally.
5. Trace the mount holes through the plate onto the wall with a pencil.
6. For masonry installation, drill two 7mm holes and insert the plastic wall plugs
7. For timber wall construction, drill two 6mm holes through the tiles/wall board only and drill 2mm pilot holes into the timber.
8. Screw into position with the stainless steel screws provided. Ensure that the mount plate is fitted level and oriented correctly with the indentation at the bottom (this is where the grub screw on the bracket fastens into the mount plate).
9. Place the bathroom accessory into position over the spigot of the plate.
10. Tighten into position with a grub screw into the fixing hole underneath the accessory and fasten in place with the Allen key provided.

