

Reva Bed Instructions

BEFORE YOU START:

Please check you have all components -

For sizes SNG & KNG SNG

- 1 x Headend
- 1 x Bed Base
- 6 x Bolts



For sizes DBL - SPR KNG

- 2 x Headend
- 2 x Bed Base
- 12 x Bolts



Step 1

Lay the bed base upside-down on a table at least 1m high.



Step 2

Move the headend underneath the bed base head end



Step 3

Screw the bolts in place firmly.



Your bed is now ready for use.
Thanks for choosing quality New Zealand made product. Enjoy!

Reva Bed Instructions

BEFORE YOU START:

Please check you have all components -

For sizes SNG & KNG SNG

- 1 x Headend
- 1 x Bed Base
- 6 x Bolts



For sizes DBL - SPR KNG

- 2 x Headend
- 2 x Bed Base
- 12 x Bolts



Step 1

Lay the bed base upside-down on a table at least 1m high.



Step 2

Move the headend underneath the bed base head end



Step 3

Screw the bolts in place firmly.



Your bed is now ready for use.
Thanks for choosing quality New Zealand made product. Enjoy!