FAT TYRE ADAPTER

Turn any SpaceRail Hook into a Fat Bike Hook

These instructions are for installing the FTA (Fat Tyre Adapter) to any Fat Bike wheel. The FTA is suitable for fat tyres from 4" to 5" only and can hold a load up to 30kg. If you are unsure on how to fit or use this product, please reach out and ask our experts or look for fitting examples and instruction videos on our website www.stashedproducts.co.uk



WARNING: ALWAYS REMOVE FAT TYRE ADAPTER BEFORE MOVING OR RIDING YOUR BIKE. FAILURE TO DO SO COULD RESULT IN DAMAGE TO YOUR BIKE OR PERSONAL INJURY. THE VELCRO STRAP MUST BE FULLY CLOSED TO ENSURE THE FULL RATED STRENGTH WHEN BIKE IS HUNG.

slot!

Contents

- FTA hanger with Velcro strap

Fitting

- 1. Open Velcro strap and extend fully
- 2. Hold FTA to center of tyre and pass Velcro strap through wheel
- 3. Loop Velcro strap through slot in FTA and pull tight
- 4. Place Velcro strap back to Velcro receiever
- 5. Ensure FTA is centered and stable on tyre and cannot move
- 6. Hang Fat Bike on to SpaceRail Hook.

Removal

- 1. Remove Fat Bike from SpaceRail Hook
- 2. DO NOT MOVE YOUR BIKE WITH FTA ATTACHED TO TYR
- 3. Remove FTA by reversing fitting procedure
- 4. Hang FTA on SpaceRail Hook for storage.











Maintenance & Checks

Your FTA is generally maintenance free, but some checks should be performed before each use. Check the Velcro strap for damage and ensure Velcro grips as expected. Retire the product if damage is apparent.

To clean, remove from bike and wipe clean with a damp cloth. Wipe dry with a clean cloth. Do not leave damp or in a damp environment. Not suitable for machine washing.



MADE IN WALES by STASHED PRODUCTS

Unit 1, Y-Glyn, Llanberis, Caernarfon, Gwynedd, LL55 4EL, UK

www.stashedproducts.co.uk sales@stashedproducts.co.uk