Ceiling LED Pendant

1a.

1b.

1c.

1d.

1e.

1f.

2a.

2b.

START FROM HERE

- · Make sure power is completely off at the fuse box.
- · Have your fixture installed by a qualified licensed electrician
- · Prepare everything in a clear area.
- · Wear gloves at all times during this installation.
- · Read instructions carefully before you start assembly.
- · Keep this instruction sheet for future reference.

Technical Support: 1-855-855-8926

Please Note:

· All Kuzco LED fixtures come with pre-wired LED module(s).

2e.

- Unless instructed to do so, please do not touch any part of the LED module(s) as any unnecessary contact with the module could cause permanent damage.
- For dimming, an ELV (Electronic Low Voltage) type of dimmer is required.

CAUTION: HEAVY FIXTURE, THE JUNCTION BOX NEEDS TO BE REINFORCED BEFORE INSTALLATION.

- Remove the fixture from its original packaging. Remove the mounting plate (1c) from within the canopy (2a) by removing the two decorative nuts (2b). Secure the mounting plate (1c) to the junction box (1a) with the screws (1e) provided in the hardware package. NOTE: heavy fixture, be sure to reinforce the junction box.
- Before you mount the canopy to the mounting plate select the desired length you wish the pendant to hang. Push conduit section (2e) upwards into the canopy (2a) and thread on washer and nut (1f). To shorten or lengthen the fixture, just remove or add conduit sections (2c) by threading clockwise for adding and counter clockwise for removing.
- LED Engine is built in. Connect the glass diffusers (3b) to the fixture chassis (2d) using the allen key and set screws (3a).
- You are now ready to mount the canopy (2a) to the mounting plate (1c). First connect all wires correctly L live wire (black to black) N neutral wire (white to white) and G ground to ground with provided marretts (1b) from the hardware package. Align the threaded screws (1d) hanging downward from the mounting plate to the holes inside the canopy (2a). Push the canopy up towards the ceiling so the two screws point through the hole in the canopy (2a). You can now screw on the decorative nuts (2b) onto the threaded studs (1d) pointing through the canopy this will securely connect the canopy to the

