

# LOLO RACKS

## **CYBERLIGHT Installation**

Install lower crossbar onto rack first if possible.

Remove lights from packaging. Wipe off interior surface of lower crossbar.

Remove film covering adhesive on light bar.

Carefully center and apply light to interior surface.

Note the Right and Left sides and location of tire notches in photo below. The ends of the light should be flush with the end of the crossbar outside edge.



Press down on light with your fingers to set the adhesive.  
Install (4) zip ties at ends for security.



Wrap wire loom around the wires and tape as needed.

If you purchased the 7pin to 4/5 pin plug adaptor see the next page.

You'll need to tap into your reverse light wiring for the white reverse function of the cyber light to work if your vehicle only has a 4 pin plug.

**Use the extra loop bungees to wrap up loose wires so they don't flop in the wind.**

Use soapy water to occasionally wipe the light surface clean and apply dielectric grease to the plug to keep it from corroding or getting stuck.



Plug in the single loose wire to the plug as shown for reverse light operation.