



WOCA Direct Canada

 1-800-401-7773  info@wocadirect.ca

WOCA WOOD LYE INSTRUCTIONS

WOCA Wood Lye (Grey or White) is used for lye priming of unfinished or newly sanded interior woodwork i.e. floors, stairs, furniture and panels. The priming minimizes the wood from yellowing and enhances the wood grain, creating a color wash effect. Wood Lye may be used on all types of wood.

Preparation:

Use protective goggles and gloves during work.

The unfinished woodwork must be sanded, clean and dry before lye application. Shake the container well. Pour lye into a plastic bucket or paint tray and stir regularly in order to get a uniform result.

Work Instructions:

1. Damp mop the floor with WOCA Intensive Wood Cleaner (see separate instructions). Let the floor dry completely.
2. Apply the lye undiluted with a brush or paint roller in an even coat on the floor, following the wood grain. Let dry overnight.
3. Apply at least one liter of lye for every 100 sq.ft. of floor or woodwork.
4. On vertical wood surfaces, apply from top to bottom.
5. Rinse tools in clean water.
6. When the wood is dry, remove any visible lime pigments from the surface. This is best done using green buffing pad under a standard floor buffer. Vacuum surface clean.
7. Finish the floor or woodwork with WOCA Diamond Active Oil.

Packaging: 2.5 liter containers

Coverage: 250 s.f.