

## **Parts Included**

Andirons x2

Legs x2

Bolts x2

Nuts x2

## **Step 1**

Place Bolt through the Andiron and Leg and secure with the Nut provided. Use supplied Allen wrench to tighten Bolts down.

