

AMG Rotisserie Kit Instructions

Included in the kit:



Motor



Motor Bracket



Set of Forks (2)



Spit Rod

Step 1: Mount the motor bracket on the left side of your American Muscle Grill by using the screws provided on the grill. It will mount at an angle.

Step 2: Slide the motor onto the motor bracket after the bracket is mounted.



Step 3: Slide the right fork onto the spit and tighten. Your choice of meat will go through the pointed side or the motor end of the spit rod. Insert the left fork and tighten.



Step 4: Hold the spit rod horizontally and insert the pointed side of the spit rod into the motor hole and rest the rod on the AMG roller wheels.



Step 5: Plug in your motor and you are ready to start using your rotisserie!

