



H-424 Low Idle Wye Installation

1. Remove existing return line from circulation pump and plug with 1/2" MPT brass or galvanized plug (if applicable).
2. Find raw water pump intake lone and remove a 5/8" section between the thru-hull fitting and the raw water pump.
3. Install the "Y" fitting as shown above with the 5/8" branch facing the correct direction.
4. Tighten hose clamps.

NOTE: After removing existing return line (step 1) be sure to extend the hose to the area on the raw water intake line where you want to install the "Y" fitting before you make the cut. To ensure enough length of hose.

HEATER CRAFT

11948 North Tracey Road
 Hayden, Idaho 83835
 contactus@heatercraft
 208-687-4400 PST

