



TOAM Sconce

coilanddrift.com
studio@coilanddrift.com
@coilanddrift

COIL +
DRIFT

BEFORE YOU BEGIN:

- + Always wear white cloth or latex gloves when handling the metal.
- + The sconce plate is 4" with horizontally aligned screws distanced 2.75" apart. A universal backplate may be used if necessary to fit available junction box.

CAUTION: ELECTRIC SHOCK RISK:

- + Coil + Drift recommends this product be installed by a qualified electrician only.
- + Disconnect power at junction box and turn off electrical power at breaker before beginning.

TOOLS REQUIRED:

- + Power drill + Drill bits + Allen key set

Having an issue? Call us at 917.664.4483

INSTALLING YOUR TOAM SCONCE:

1.
We recommend using a circular junction box that is under 4 inches in diameter with screwholes spaced horizontally and 2.75" apart. The sconce backplate is solid, not pressed. Make sure junction box lays flush with the wall so that the plate lays flush against the outer wall when installed.

2.
Wire individual leads to line power in junction box, then screw backplate to junction box.

Note: If junction box screw holes are not placed horizontally or are not space 2.75" apart, first consider replacing the junction box. If you must use the existing box, use a universal backplate that is under 4" in diameter and inset the junction box so the universal backplate lays flush with the outer wall. If you don't do this your universal backplate will be visible once the sconce is installed because the sconce backplate is flat and solid, not pressed.

Enjoy your new Toam Sconce!

