



METHODS OF APPLICATION

Osmo Polyx®-Oil High Solid is ready to use, please do not thin. Stir carefully before use.

First coat: Apply thinly and evenly with the wood grain using an Osmo Hand Brush, an Osmo Floor Brush or Osmo Floor Roller. Leave to dry for at least 8 - 10 hours. Ensure good ventilation and room temperatures above 18° C.

Second coat: Apply thinly as above. Remove surplus immediately. Alternatively apply second coat by scraper and buff the surface with a white pad. Leave to dry at least 8 - 10 hours, ventilate well. When thoroughly dry, surface can be buffed or polished with hand polisher or buffing machine.

When renovating or re-coating an already oiled surface, one coat applied to the clean and dry surface is usually sufficient.

Note: The finish can alternatively be polished into the floor using a single disc machine and non abrasive pad.