

**MULTI-SURFACE**  
**CERAMIC**  
**CLEARCOAT**  
**PURE AIR COATING**

**Transition VCT to  
SIMIX Multi-Surface  
Ceramic Clearcoat**

**You will need:**

Mop/mop bucket  
175 RPM floor buffer  
Front-mounted squeegee wet vacuum  
Auto scrubber  
220#, 800# diamond pads  
Buff diamond polishing pad (8500 grit)  
2-4 gallon pump-up sprayer  
18" or 24" microfiber flat mop system  
(Pads are short-looped and laundered)  
**SIMIX Multi-Surface Cleaner & Degreaser**  
**SIMIX Multi-Surface Ceramic Clearcoat**  
Distilled or RO water

**INSTRUCTIONS**

**It is imperative that the floor is completely stripped**

**Step 1:** Strip floors of all wax. Make sure all edges are done well.

**Next steps are done using auto scrubber**

**Step 2:** Auto scrub floor using one large scoop of **SIMIX Multi-Surface Peroxide Cleaner & Degreaser** per tank of warm water. Make 4 passes using 220 diamond pads. Pick up slurry. This will start to smooth the floor and remove oxidation from years of stripping.

**Step 3:** Auto scrub floor with only 2 small scoops of **SIMIX Multi-Surface Peroxide Cleaner & Degreaser** per tank full on scrubber making 4 passes using 800 diamond pads. This will smooth the floor to the point that a nice shine is present. Pick up slurry.

**Step 4:** Auto scrub floor with diamond buff and 2 small scoops of cleaner per tank make 2 passes and pick up water. Let floor visibly dry.

If floor is without residue apply **Simix Multi-Surface Ceramic Clearcoat**.

**Step 5:** Shake **Simix Multi-Surface Ceramic Clearcoat** bottle well. Mix 4 parts water (use distilled or RO water) to one-part coating in pump up sprayer. Spray on floor and apply using laundered short-looped microfiber flat mop. Rinse mop head after 500 to 1000 sq. ft. of floor in warm clean water. Apply 4 thin coats. Apply each coat after floor dries. The coating will take from 5 to 15 minutes to dry.

**Next day**

Clean floor with auto scrubber. 1 large scoop per tank of warm water and diamond buff pads. Make 2 passes and pick up water. Let visibly dry.

**Apply 4 – 8 coats**

For maximum shine, base coating for grocery store should be 8 to 12 coats.

The floor will increase in shine over the coming weeks with daily auto scrubbing using diamond buff pads. Try to use diamond buff pads 3x-5x per week for maximum clean and shiny floor.

