

INSTALLATION INSTRUCTIONS

PART No.

FB21110

Jeep® JL Wrangler 2018-Current Light Bracket - Cowl

QTY

1 EA

1 EA





REQUIRED TOOLS T-40 Torx KIT CONTAINS Cowl Light Bracket (Left & Right) Foam Padding (Left & Right)

2111001



INSTALLATION INSTRUCTIONS

PART No.

FB21110

Jeep® JL Wrangler 2018-Current Light Bracket - Cowl

1) REMOVE OEM WINDSHIELD SUPPORT (COWL) BOLTS

If you already have aftermarket parts installed, remove them. Using a T40 Torx bit, remove the two top bolts and washers from the vehicle's windshield support/cowl.





2) INSTALL LIGHT BRACKET

Place the bracket into the holes, spacer side down, with the slotted flange pointing towards the center of the vehicle.

NOTE

If you are installing the light bar brackets with the foam backing you will need to apply pressure to the light mount when installing.



Secure it by replacing the Torx bolts and washers.



Repeat steps 1&2 on the opposite side.



2111001

1



INSTALLATION INSTRUCTIONS

PART No.

Jeep® JL Wrangler 2018-Current Light Bracket - Cowl

FB21110

3) LIGHTING

Install your 40"–42" light bar or cube lights of choice following the manufactures instructions.



ENJOY YOUR NEW FISHBONE OFFROAD COWL LIGHT BRACKETS!