

FISHBONE  
OFFROAD



## INSTALLATION INSTRUCTIONS

**PART No.**

**FB21300**

**Universal for 2" Hitch Receiver  
2" Hitch Basket**



### REQUIRED TOOLS

Ratchet  
13mm Socket  
5mm Hex Wrench  
Hitch Pin

### KIT CONTAINS

Hitch Basket  
Hitch Support Bracket  
Button Head Bolt  
Flat Washer  
Nylock Nut

### QTY

1  
1  
4  
8  
4

## INSTALLATION INSTRUCTIONS

**PART No.** FB21300  
**Universal for 2" Hitch Receiver**  
**2" Hitch Basket**

**1) INSERT**

Remove any existing cover or hitch pin from your 2" hitch.



Insert the Support Bracket so that the flat side of the brackets point up.



Slide it to the hitch hole which allows the closest bracket to sit about 3 inches from any above obstruction.



Secure the Support Bracket with the vehicle's hitch pin.



**2) ASSEMBLE**

Place the Basket onto the Support Bracket so that our signature logo plate faces outwards.



Line up the bolt holes with the Bracket's, and secure it with the included hardware and a 13mm socket and 5mm hex wrench: Bolt, washer, Basket, Bracket, washer, and Nylock nut.



**ENJOY YOUR FISHBONE OFFROAD HITCH BASKET!!!**