



INSTALLATION INSTRUCTIONS

PART No.

FB21350

**2020 6th Gen. Ford Bronco
Light Pod Bracket**



VIDEO AVAILABLE



REQUIRED TOOLS

T25 Torx Bit

KIT CONTAINS

Light Pod Bracket (Driver/Passenger)

QTY

1ea

2135000

1) ASSEMBLE

Install your pod lights of choice following the manufacturer's instructions. You can tell which bracket installs on to which side of the vehicle based off of the antenna cutout and shape.



2) REMOVE

With a T25 Torx Bit, remove the 2 cowl bolts from each side, just above each mirror.



3) INSTALL

Place the respective bracket and pods over the cowl and secure it with the factory bolts removed in Step 2.

