



## INSTALLATION INSTRUCTIONS

**PART No.**

**FB213XX**

**Ford/Toyota/Dodge/GMC/Chevy  
Side Steps**

Applicable to all the below Part#s

FB21373, FB21374, FB21375, FB21376  
FB21377, FB21378, FB21379, FB21380  
FB21381, FB21382, FB21383, FB21386  
FB21387



**VIDEO AVAILABLE**



### REQUIRED TOOLS

13mm Socket

### KIT CONTAINS

Side Step (Driver/Passenger)  
Mounting Brackets  
M8 Hex Bolts  
M8 Washers  
M8 Lock Washers  
M8 Nyloc Nuts  
Clip-on Nuts  
Plastic Washers

### QTY

1ea  
4-6

2137400

## INSTALLATION INSTRUCTIONS

**PART No.**

**FB213XX**

**Ford/Toyota/Dodge/GMC/Chevy  
Side Steps**

**1) REMOVE EXISTING STEPS**

Begin removing your vehicle's existing steps, if applicable.



**2) INSTALL BRACKETS**

Begin installing your mounting brackets. According to which vehicle you have, they will be installed in one of two ways: Ford, Dodge, and Toyota will share the same method, and Chevy/GMC will install another way.



**FORD/DODGE/TOYOTA**

Install the plastic washers onto the factory step studs.



Each of the mounting brackets are marked to indicate its orientation.



Install the brackets in their designated location with the included hardware with a 13mm socket.



## INSTALLATION INSTRUCTIONS

**PART No.**

**FB213XX**

**Ford/Toyota/Dodge/GMC/Chevy**

**Side Steps**

### CHEVY/GMC

If you either don't have them, or you wish to replace them, included with the hardware are clip on nuts. Install them at the bottom and interior factory locations at this time.



At the front of the vehicle on the passenger side, install the included upper bracket and bolt plate onto the vehicle, as shown, with a 13mm socket. Insert the stud through the clip.



Install the brackets according to their designated location.



### 3) **INSTALL THE STEP**

Install the step by placing them on the brackets with the remaining hardware with a 13mm socket.

