



# INSTALLATION INSTRUCTIONS

**PART No.**

**FB22361**

**2021+ Toyota Tacoma 3rdGen  
Rear Bumper**



**VIDEO AVAILABLE**



## REQUIRED TOOLS

15mm Socket  
4mm Hex Wrench  
10mm Socket  
3mm Hex Wrench

Help of a friend

## KIT CONTAINS

Rear Bumper  
M6 Washer  
M6 Nut  
M6x16mm Button Head Bolt  
M10 Flange Nut  
D-Ring  
M6x40mm Button Head Hex Bolt  
M6x45mm Button Head Hex Bolt  
M6 Bolt Spacer  
M6 Nyloc Nut

## QTY

1  
4  
4  
8  
10  
10  
2  
4  
2  
6  
10

2236100

## INSTALLATION INSTRUCTIONS

**PART No.**

**FB22361**

**2021+ Toyota Tacoma 3rdGen  
Rear Bumper**

**1) REMOVE EXISTING BUMPER**

Begin removing your vehicle's existing rear bumper. We show how to remove and disassemble your factory bumper over at

[www.YouTube.com/FishboneOffroad](http://www.YouTube.com/FishboneOffroad)

**2) ASSEMBLE**

Begin by installing your blind spot monitoring sensors with the included M6 45mm bolts, nyloc nuts, and bolt spacers with a 4mm Hex wrench and a 10mm wrench/socket. Note: These are side specific.

Install your pod lights, factory license plate lights, and factory trailer connector.



Loosely install the frame brackets onto the back of the bumper with a 15mm wrench, and 13mm socket using 4 of the included M10x35mm flange bolts. They will need adjusting later.



Install your backup sensors with a 3mm Hex Wrench. Again, these are location specific. Ensure they're installed into the same bracket location as the factory bumper.



## INSTALLATION INSTRUCTIONS

**PART No.**

**FB22361**

**2021+ Toyota Tacoma 3rdGen  
Rear Bumper**

**3) INSTALL**

With the help of a friend hold the bumper up to the truck, and with the remaining M10 flange bolts, secure the bumper to the vehicle using a 13mm socket.



Adjust and center the bumper, and verify tailgate clearance.

Completely tighten down each bolt.



Reconnect your license plate lights, pod lights, and sensor harnesses.



Verify sensor function and install your D-Rings.

