



# INSTALLATION INSTRUCTIONS

**PART No.**

**FB22367**

**07-13 Chevy/GMC 1500  
Rear Bumper**



**VIDEO AVAILABLE**



## REQUIRED TOOLS

17mm Socket  
21mm Wrench  
22mm Socket

Help of a friend

**You will need to purchase 2014-2018  
Chevy/GMC style license plate lights  
to accommodate our mounting  
brackets.**

## KIT CONTAINS

Chevy Rear Bumper  
D-Ring  
Bumper Rail Brackets  
M14 Hex Bolt  
M14 Nyloc Nut  
M14 Washer  
M10 Hex Bolt  
M10 Nyloc Nut  
M10 Washer  
M6 Counter Sunk Screw  
M6 Nyloc Nut  
M6 Washer  
M6 Button Head Bolt

## QTY

1  
2  
2  
8  
8  
16  
2  
2  
4  
2  
2  
2  
6

2236700



## INSTALLATION INSTRUCTIONS

**PART No.**

**FB22367**

**07-13 Chevy/GMC 1500  
Rear Bumper**

**1) REMOVE EXISTING BUMPER**

Begin removing your vehicle's existing rear bumper, fog lights, sensors, and grille. We show how to remove and disassemble your factory bumper over at

[www.YouTube.com/FishboneOffroad](http://www.YouTube.com/FishboneOffroad)



**2) ASSEMBLE**

With a 21mm wrench, 22mm socket, and 17mm socket, install the bumper brackets onto the frame rail with 4 out of the 8 M14 bolts and nuts, as well as an M10 bolt, 2 washers, and nut on each side.



**3) INSTALL**

With the help of a friend, lift the bumper up to the bumper brackets and loosely secure it with the remaining M14 bolts. Adjust and center the bumper as desired, and completely tighten the bumper down.



## INSTALLATION INSTRUCTIONS

**PART No.**

**FB22367**

**07-13 Chevy/GMC 1500  
Rear Bumper**

Install your license plate lights into the bumper with the included plastic push clips. Install your trailer connector using the included M6 bolts and nuts, followed by securing the wiring harness as desired.

