



INSTALLATION INSTRUCTIONS

PART No.

FB22392

**14-21 Toyota Tundra
Front Winch Bumper**



VIDEO AVAILABLE



REQUIRED TOOLS

18mm Socket
14mm Socket

Help of a friend

KIT CONTAINS

Front Bumper
Mounting Bracket
M12 Hex Bolt
M12 Washer
M12 Flanged Nut
M6 Screw
M6 Nyloc Nut
Pod Light Bracket

QTY

1
2
4
4
4
8
8
2

2239200

14-21 Toyota Tundra Front Winch Bumper

1) REMOVE EXISTING BUMPER

Begin removing your vehicle's existing front bumper and sensors. We show how to remove and disassemble your factory bumper over at www.YouTube.com/FishboneOffroad



2) ASSEMBLE

Install your winch into the bumper.



Assemble the bumper by loosely securing the mounting brackets with the included hardware with an 18mm socket. Their orientation can be determined by the sides with the three bolt holes facing outward.



Install all your sensors, pod lights, and power harness. Depending on the type of pod light you purchased, you may need to use the pod light brackets and M6 bolts to mount your light.



3) INSTALL

With the help of a friend, Secure the bumper to the frame with the factory hardware, using a 14mm socket. Once secured, adjust and center the bumper, and fully tighten the mounting brackets.

