



Jeep® JL Wrangler Front Roll Bar Flashlight Mount



REQUIRED TOOLS

Torx T25 Screw Driver

KIT CONTAINS

Flashlight mount

QTY

1

1. OPENING ROOF

Using Manufacture instructions raise the roof to create headroom while installing the flashlight mount.



2. LOCATE TORX SCREWS.

Remove the two T-25 Torx Screws on top of the roll cage.



3. PLACE FLASHLIGHT MOUNT ONTO ROLL CAGE

Reusing the two T-25 Torx Screws secure the flashlight mount.



4. INSTALL FLASHLIGHT.



5. RESECURE ROOF.