



# INSTALLATION INSTRUCTIONS

**PART No.**

**FB25101**

**Jeep® JL Wrangler  
Wheel Well Storage Bins**



## REQUIRED TOOLS

T50 Torx Bit  
5mm Allen

## KIT CONTAINS

Storage bins (Left and Right)  
Quick Install Knobs  
Washers  
Lock Washers (for soft-tops only)  
Button Head Bolts (for soft-tops only)

## QTY

1 EA  
4  
4  
2  
2

There are three (3) installation methods depending on your Jeep's current configuration. Please follow the instructions accordingly:

- A. Hard top with top on
- B. Hard top with top off
- C. Soft top\* – with top up or down

### A. FOR HARD TOP MODELS WITH TOP ON:

#### 1) UNBOLT YOUR HARD TOP

Inside your lift gate your hardtop will be bolted down by 6 bolts, with 3 on either side. Remove the innermost 2 on either side using a T50 Torx bit.



#### 2) INSTALL STORAGE BINS

Place the corresponding bin over the bolt holes.

Either using all of your OEM hardware, or the supplied four (4) knobs and washers, secure the storage bins in place.

2510100

### Jeep® JL Wrangler Wheel Well Storage Bins

**NOTE:** Hard top Jeeps will not use the supplied lock washers and button head bolts.



#### B. FOR HARD TOP MODELS WITH TOP OFF:

##### 1) **INSTALL STORAGE BINS**

With the top already off the Jeep, simply place the storage bins over the 2 innermost hardtop holes. Secure them in place using the supplied knobs and washers or your OEM hardware.

\*To reinstall your hardtop, you must uninstall the storage bins first.



#### C. FOR SOFT TOP MODELS

##### 1) **INSTALL STORAGE BINS**

With or without the soft top on (or down), pull back the carpet and screw in one of the supplied bolts into the OEM nut plate just below the plastic C-pillar.



## Jeep® JL Wrangler Wheel Well Storage Bins

Do so until 1 to 2 threads are visible.



Repeat on the opposite side.  
Resecure your soft-top.



**ENJOY YOUR NEW SET OF FISHBONE OFFROAD  
WHEEL WELL STORAGE BINS!**



Push the bin's bracket under the pillar and over the bolt threads until it sits evenly with the tub rail.

Secure the remaining bracket with either your OEM Torx bolt or one of the supplied quick knobs and washer.

