

INSTALLATION INSTRUCTIONS

PART No.

FB25215

Jeep® JL 4DR* Wrangler Wheel Well Storage Bin – Drivers Side Only







REQUIRED TOOLS

T-40 Torx

KIT CONTAINS	QTY
Storage bin – Drivers Side	1
Quick install knobs	2
Washers	2
Button Head Bolt	1
Lock Washer	₫ dd

There are three (3) installation methods depending on your Jeep's current configuration. Please follow the instructions accordingly:

- A. Hard top with top on
- B. Hard top with top off
- C. Soft top* with top up or down

A. FOR HARD TOP MODELS WITH TOP ON:

1) REMOVE HARDTOP BOLTS

Remove the two inner T-40 hardtop bolts on each side.





2) INSTALL STORAGE BIN

Place the storage bin either above or beneath hardtop lip.

2521500



INSTALLATION INSTRUCTIONS

PART No.

FB25215

Jeep® JL 4DR* Wrangler Wheel Well Storage Bin – Drivers Side Only



Either using all of your OEM hardware, or the supplied two (2) knobs and washers, secure the storage bin in place. Reuse your factory hardware to finish securing your hard top.

NOTE: Hard top Jeeps will not use the supplied bolts.

B. FOR HARD TOP MODELS WITH TOP OFF:

1) INSTALL STORAGE BIN

With the top already off the Jeep, simply place the storage bin on top of the Jeep tub and align above the factory holes. Secure in place using the supplied knobs and washers and utilize the OEM hard top nut with clip.

C. FOR SOFT TOP MODELS

1) INSTALL STORAGE BIN

With or without the soft top on (or down), pull back the carpet and screw in one of the supplied bolts into the OEM nut plate just below the plastic C-pillar.









INSTALLATION INSTRUCTIONS

PART No.

FB25215

Jeep® JL 4DR* Wrangler Wheel Well Storage Bin – Drivers Side Only

Do so until 1 to 2 threads are visible.





Push the bin's bracket under the pillar and over the bolt threads until it sits evenly with the tub rail.

Secure the remaining bracket with either your OEM Torx bolt or one of the supplied quick knobs and washer.





ENJOY YOUR NEW FISHBONE OFFROAD STORAGE BIN!