



INSTALLATION INSTRUCTIONS

PART No.

FB25232

**Jeep® '07-'18 Current JK Wrangler
Tub Rail Tie Downs**



REQUIRED TOOLS

13MM Socket
Ratchet

KIT CONTAINS

JK Tub Rail Tie Down (Left & Right)
Hardtop Knobs
5/16" Flat Washer
M8 Hex Nut

QTY

1 ea
4
8
4

1) REMOVE TUB ACCESSORIES

Prepare the installation area by removing any accessories from your tub rails, including our storage racks, bins, and any hardtop Torx bolts.



Depending on your preference or setup, the Tie Down will sit on top of any accessory, meaning the included knobs will secure it and anything extra.



2) TIE DOWN ORIENTATION

Determine the orientation you'd like for the Tie Downs, as they're driver and passenger side specific, but can be swapped by rotating them to face inboard or outboard.



3) INSTALL

Place all your desired accessories onto the rail with the Tie Down finally on top. With 2 of the included knobs, 4 washers, and 2 hex nuts, secure the Tie to the tub rail with a 13mm socket.





If you own a Hardtop, you do not need to use the hex nuts and 4 of the washers.

Repeat on the opposite side.

**4) ENJOY YOUR NEW FISHBONE OFFROAD TUB RAIL
TIE DOWNS!**

