

INSTALLATION INSTRUCTIONS

PART No.

FB31043

**Jeep® JK Wrangler
Fishbone Offroad Taillight Covers**



REQUIRED TOOLS

Phillips Screwdriver

KIT CONTAINS

Taillight Cover
No. 8 Screw
No. 10 Screw
Plastic Spacer

QTY

2
4
4
8

1) REMOVE TAILLIGHT SCREWS

Remove your OEM or existing taillight cover using the Phillips screwdriver.



between the taillight cover and your taillight. Install two No. 10 screws and two spacers into the outside holes.



2) INSTALL TAILLIGHT COVER

CAUTION!

THE SCREWS CLOSEST TO THE TAILGATE ARE NO. 8, AND THE SCREWS ON THE OUTSIDE OF YOUR JEEP ARE NO. 10. TAKE CARE TO NOT MIX THESE UP TO AVOID DAMAGE TO YOUR TAILLIGHT HOUSINGS!

Install two No. 8 screws and spacers into the holes closest to the tailgate. Ensure the spacers are

Tighten screws with the screwdriver. **DO NOT OVERTIGHTEN!**

3) REPEAT ON OPPOSITE SIDE

4) ENJOY YOUR NEW FISHBONE OFFROAD TAILLIGHT COVERS!