



INSTALLATION INSTRUCTIONS

PART No.

FB33130F

2018 – Current JL Wrangler
Front Aluminum Inner Fenders



REQUIRED TOOLS

- 3mm Allen
- 10mm Socket
- (2) 8mm Wrench
- Drill
- 9/32" Bit

RECOMMENDED TOOLS

- M5 Nutsert Tool

KIT CONTAINS

Front Inner Fender Set (Driver/Passenger)

- | | QTY |
|---|------------|
| Front Inner Fender Set (Driver/Passenger) | 1 |
| M5 10mm Stainless Washer | 14 |
| M5 Stainless Flange Nut | 6 |
| M5 Threaded Rivet | 4 |
| M5 Steel Hex Bolt | 2 |
| M5 16mm Button Head Bolt | 14 |
| M5 15mm Washer | 4 |
| M5 Steel Hex Nut | 2 |

1) PREPARE YOUR VEHICLE

Remove your vehicle's existing inner and outer fenders. Please visit Fishbone Offroad on YouTube for instructions on how to remove your OEM parts.



Within the driver and passenger **front** wells, and with a 9/32" drill bit, expand the two frame holes that are shown below.




With either an M5 Nutsert Tool **OR** (1) 25mm bolt, M5 hex nut, 10mm washer, and (2) 8mm wrenches, install an included nutsert into each hole.



2) ASSEMBLE YOUR FENDERS

Loosely assemble your rear fender top and bottom using (7) 10mm button head bolts, washers, and flange nuts. With a 3mm Allen key, ensure the grate and plate hardware is secured before continuing.



OPTIONAL 1: The accent grates and plates can be removed with a 3mm Allen key to be painted separately.


INSTALLATION INSTRUCTIONS

PART No.


FB33130F

2018 – Current JL Wrangler

Front Aluminum Inner Fenders



Secure the bottom with (2) 16mm bolts and 15mm washers into the frame nutserts previously installed.



3) INSTALL YOUR FRONT FENDERS

Starting with the rear, logo-less section, begin securing the fender to the body with (2) 16mm bolts and washers.



Tighten all visible bolts with a 3mm Allen key.

Repeat on the opposite side.

4) REINSTALL YOUR OUTER FENDERS

Reinstall your outer fenders according to the manufacturer's instructions.

OPTIONAL: If your vehicle has Fishbone Offroad Tube Fenders, the rear inners and outers will share the rear most bolt hole. Using an M8 bolt and washer, secure the two to the body.

With (2) 16mm bolts and washers, secure the front section to the rear section rivets.



Repeat on the opposite side.

Secure the top with a 16mm bolt, washer, and nut.



INSTALLATION INSTRUCTIONS

PART No.

FB33130F

2018 – Current JL Wrangler
Front Aluminum Inner Fenders

- 5) **ENJOY YOUR NEW FISHBONE OFFROAD ALUMINUM INNER FENDERS!**

