

Open Shelf Vanity Assembly Guide

Tools and Materials Needed for Assembly:

- Staple Gun with 1/2" staples
- Drill
- Hammer and Mallet
- Wood Glue
- Bar Clamp
- Marking Jig
- Knife
- Pencil

Instructions:

- 1.) Position glide bracks on the back panel and secure with screws.
- 2.) Insert dowels into the vanity legs. Then, tap them into place with a mallet.
- 3.) Screw feet into the bottom of the vanity legs.
- 4.) Attach legs to the back panel and tap into place with a mallet.
- 5.) Attach side panels to the vanity legs and tap into place with a mallet.
- 6.) Attach the front legs to the side panels and tap into place with a mallet.
- 7.) Attach face frame to the front legs and tap into place with a mallet.
- 8.) Attach the shelf to the vanity legs and tap into place with a mallet.
- 9.) Use a bar clamp to tighten the legs.
- 10.) While clamped, attach assembly blocks on the inside of the vanity box where the sides and legs meet with staples.
- 11.) Apply wood glue to the drawer front dovetails.
(Note: The drawer box front is pre-attached to the drawer head).

- 12.) Insert the drawer box side pieces into the face frame dovetails. Then, use a mallet to tap the dovetails into place.**
- 13.) Insert the bottom panel into the drawer box.**
- 14.) Apply wood glue to the center cutout panel dovetails.**
- 15.) Attach sides to center cutout and tap into place with a mallet.**
- 16.) Insert center cutout into the drawer box bottom.**
- 17.) Apply wood glue to the 2 back panels' dovetails and insert them into the drawer box back. Tap them into place with a mallet.**
- 18.) Secure the bottom panel to the side panels with staples at a 45-degree angle.**
- 19.) Secure with drawer glide clips to the drawer box with screws.**
- 20.) Place bumpers on the drawer box.**
- 21.) Apply wood glue to the front panel dovetails of the second drawer box front panel. Attach the side panels to the front panel dovetails and tap into place with a mallet.**
- 22.) Position the side panels and insert the bottom panels into the side panel dadoes.**
- 23.) Apply wood glue to the back panels and attach them to the side panels. Tap them into place with a mallet.**
- 24.) Use the pilot holes to secure the side panels to the front panel.**
- 25.) Use the pilot holes to secure the drawer box to the face frame.**
- 26.) Secure the drawer glide clips to the bottom of the drawer box with screws.**
- 27.) Place bumpers on the back of the drawer front, and then insert your drawer boxes so that clips are attached to the drawer glides.**
- 28.) Enjoy your new open-shelf bathroom vanity!**