

INSTRUCTIONS

ARMOURED LABS SNOW PREMIUM SERIES Application Instructions

Congratulations on your purchase of Armoured Labs SNOW. This Ultra Hydrophobic Ceramic Nano-Coating (WAX Replacement) is designed specifically to enhance glide & reduce ice stickiness. It protects and prolongs the life of SnowSkates, Snowboards, Splitboards, Skis, Snowmobiles, Snow Goggles, or Toys used in downhill winter sports.

SURFACE PREPARATION

1

- Ensure surfaces are clean and free of debris. Remove all traces of previous coatings such as Wax.
- Ensure your surface is dry before beginning your application.
- For best results, we recommend applying your nano-coating indoors in temperatures between 41°F - 86°F (5°C - 30°C).

APPLYING THE COATING

2

- Turn the spray nozzle to the open position.
- Holding your spray bottle approx. 4" (10cm) away from the surface, spray the nano-coating liberally over all surfaces you wish to coat.
- Armoured Labs SNOW dries almost immediately. If applying to lenses of Snow Goggles, wait 5 minutes before buffing off excess residue with a microfibre or soft cotton cloth.
- Wipe off excess residue with a microfibre or soft cotton cloth excluding foam and stomp pads.

POST APPLICATION

3

- Wait 4 hours from when you applied the nano-coating before getting wet.
- Shred on! Re-apply as required. Your Armoured Labs SNOW nano-coating will last an average of 4-12 sessions before re-application is required, depending on how hard you shred!

**GET ARMoured!
STAY PROTECTED!**

WWW.ARMouredLABS.COM

US-AL-96584-IN

