INSTRUCTIONS

RMPEEL

Prepress shirt for 5 seconds

HEAVY PRESSURE

310-330 F 10-20 seconds

Peel WARM

We found it was best to let sit for a few seconds before peeling. Use a cloth and rub the print with pressure before peeling.

It is recommended to press again for 5-10 seconds once film is peeled. Can be covered with parchment/butcher paper, teflon sheet, or no cover. Prepress shirt for 5 seconds

CREENP

SINGLE COLOR 325 F-350 F

PRESS 8-10 SECONDS

HEAVY PRESSURE

CLEAR FILM 325 F-350 F

PRESS 15-20 SECONDS

HEAVY PRESSURE!

Peel HOT

USTOMD

Prepress shirt for 5 seconds 325F for 15 seconds

HEAVY PRESSURE

Remove the garment from the press and let it stand until it is **COOL**, then peel film off.

Cover the image with parchment paper and press again for 15 seconds.

*Please note: If the image does not come off completely, repress with the image in place, let it cool, and repeal the film.

Peel COLD

Iron on patch instructions on next page.

Do not wash or wear the garment for 24 hours after pressing As with any product, the longevity of your design will be directly related to how you treat it. Wash inside out, cold, delicate cycle, and hang to dry. Top T is NOT responsible for pressing errors, application errors and washing errors.*

IRON ON PATCHES:

COMMERCIAL HEAT PRESS REQUIRED

Prepress shirt for 5 seconds 325-350F HEAVY PRESSURE

Lay patch on garment and cover with teflon or parchment paper.

Press for 20 seconds.

Turn garment inside out and press another 20 seconds.



SUBLIMATION:

Ready to press.

Colors will be brighter once pressed.
Sublimation ink shows best on high polyester count fabric, does not work on dark colors or cotton. We recommend at least 50% polyester.
Must use heat press to apply (we recommend 400 degrees F for 60 seconds).

All of our transfers are printed on high quality sublimation paper and high quality sublimation ink.

**WE DO NOT GIVE PRESSING INSTRUCTIONS FOR TUMBLERS AS EACH PRESS AND OVER IS DIFFERENT.