

DIAMOND BODY PREP INSTRUCTIONS

① CLEAN THE SURFACE

Ensure Substrate is clean and decontaminated.



② SHAKE THE BOTTLE

Shake **DIAMOND BODY PREP** well for 15 seconds or longer. Spray 1-2 times into an a microfiber towel to prime it.



③ APPLY COATING

Apply **Diamond Body Prep** evenly to a microfiber towel. Re-apply more sprays of product to the towel as needed.



④ WIPE OFF

Immediately buff off residue with a microfiber towel.



INSTALLATION TIPS

- For use on most interior and exterior surfaces.
- Do NOT use on glass.