

# DIAMOND WRAP INSTRUCTIONS

## 1 PREP THE SURFACE

Ensure PPF or Vinyl is wiped down with **DIAMOND BODY PREP**.



## 2 SHAKE THE BOTTLE

Shake **DIAMOND WRAP** well for 15 seconds or longer. Place 15-20 drops to an applicator to prime it.



## 3 APPLY COATING

Apply the coating to 1-2 elements of the car in a crosshatch fashion. Re-apply several more drops of product to the applicator as needed.



## 4 WAIT & WIPE

Wait 1-3 minutes, then wipe off the excess coating. Try to look for lines and droplets indicating the coating is ready for wipe-off.

(Wipe off time varies with temperature, humidity, and file type.)



## INSTALLATION TIPS

- For Matte & Satin Films, be prepared to use slightly more product than with gloss films.
- Use separate microfiber towels for wiping off **Diamond Body Prep** & **Diamond Wrap**.
- Freshly installed films only need quick wipe down with **Body Prep**.
- For aged films, a wash, decontamination, and **Body Prep** wipe down are required before applying **Diamond Wrap**.
- If you experience a high spot while coating, re-apply **Diamond Wrap** to the affected surface & immediately wipe off.

## SCAN TO WATCH INSTRUCTION VIDEO!

