

# DIAMOND BIKE INSTRUCTIONS

## 1 PREP THE SURFACE

Ensure all bicycle elements are wiped down with **DIAMOND BIKE PREP**.



## 2 SHAKE THE BOTTLE

Shake **DIAMOND BIKE** well for 15 seconds or longer. Place 15-20 drops to an applicator to prime it.



## 3 APPLY COATING

Apply the coating to 1-2 elements of the bicycle in a crosshatch fashion. Re-apply several more drops of product to the applicator as needed.



## 4 WAIT & WIPE

Wait 3-5 minutes, then wipe off the excess coating. You may notice defined lines followed by micro droplets of the coating, this indicates the coating is ready to be wiped off.

(Wipe off time may vary due to ambient temperature, humidity, and substrate type.)



## INSTALLATION TIPS

- Safe on all hard surfaces.
- Use separate microfiber towels for wiping off **Bike Prep** & **Diamond Bike**.
- Polishing is not required before application, but is strongly recommended.
- If you experience a high spot while coating, re-apply Diamond Bike to the affected surface & immediately wipe off.