

MAKE: HYUNDAI

MODEL: STARIA

TYPE: VAN

YEARS OF MANUFACTURE: 2021-


PART NUMBER: CBHSTA21

POSITION: BEHIND 1ST ROW



KIT:

- ☐ 2 X CBHSTA21-B-001 G3-04-07
- ☐ 2 X 150MM BRACKET OFFSET SHARP
- ☐ 2 X 150MM BRACKET OFFSET
- ☐ 4 X M6X20 DOME HEAD BOLTS
- ☐ 4 X M6 WASHER SMALL
- ☐ 4 X M10X20 SET SCREW
- ☐ 4 X M10 WHIZ NUTS
- ☐ 2 X M10X55 x 1.25 HEX HEAD
- ☐ 2 X M10 WASHER SMALL
- ☐ 2 X 16X25MM SPACER



Your kit was packed by: _____

ALLWAYS CHECK FOR FUEL LINES ETC BEFORE DRILLING AND ALWAYS USE A DRILL STOP.



VIC
25 Kalman Drive
Boronia VIC 3155 Australia

NSW
376 Hoxton Park Road
Prestons NSW 2170 Australia

Tel: 1800 FLEET FIT (353 383)
autosafe.com.au

1. Remove set of tie downs from vehicle floor directly behind 1st row seats.
2. Fit CBHSTA21-B-001 to factory points above sliding door opening, on both sides using M6x20 Dome Head bolts and M6 Washers.



3. Place barrier into position and secure top lugs to previously fitted bracket using M10X20 Set screw and M10 Whiz nut. Ensure barrier is resting on top of carpet.



VIC
25 Kalman Drive
Boronia VIC 3155 Australia

NSW
376 Hoxton Park Road
Prestons NSW 2170 Australia

Tel: 1800 FLEET FIT (353 383)
autosafe.com.au

4. Secure 150MM Bracket Offset Sharp to lower tag using M10X20 Set screw, M10 Whiz nut, and reusing original tie down bolt.



5. Vehicles with a fitted floor. Replace 150MM Offset bracket sharp with 150MM bracket offset. Use 16X25MM Spacer in floor, followed by bracket, M10 Washer, secured with M10X50 1.25 Hex Head bolt.



CHECK OVER FIXINGS SYSTEMATICALLY TO MAKE SURE THEY ARE ALL TIGHT.



VIC
25 Kalman Drive
Boronia VIC 3155 Australia

NSW
376 Hoxton Park Road
Prestons NSW 2170 Australia

Tel: 1800 FLEET FIT (353 383)
autosafe.com.au