

Installation Instructions



1. Cut a round hole in the wooden ceiling. (Cutout template included)
2. Install the ring in the hole with a rubber hammer until the ring is flush with the ceiling.
3. Fasten the screws into the ring's holes to ensure a rigid grip (Allen Key included)
4. Interlock the adapter on to the module by twisting it clockwise.
5. Twist the module clockwise into the installed ring for final installation.

