

## MOLDING | INSTALLATION GUIDE

### TOOLS REQUIRED

- Miter Saw or Power Saw
- Tape Measure
- ¼" Spacers
- Construction Adhesive

### FLUSH STAIRNOSE INSTALLATION

1. Remove plastic wrap.
2. Cut the molding to required length as necessary with a power miter saw (for the cleanest cut). Be sure to wear a dust mask and appropriate eye protection when using a power miter saw.
3. Apply a generous bead of construction adhesive along the clean stair.
4. Touch the bottom of the molding to the stair riser and carefully roll the stair into place. Once the molding is in its final position, press down firmly with your hands over the length of the stairnose. *Note: The stairnose is not meant to "click" into the floor plank. The stairnose will simply lay flush alongside the floor plank.*
5. Let adhesive cure to directions. Finishing nails can be used for added security.

### T-MOLDING / REDUCER / END CAP INSTALLATION

1. Remove plastic wrap and set aside any plastic/metal track to recycle or discard. *Note: Tracks are not recommended for installation due to potential thickness mis-match between the center mounting foot and your flooring.*
2. Cut the molding to required length as necessary with a power miter saw (for the cleanest cut). Be sure to wear a dust mask and appropriate eye protection when using a power miter saw.
3. Allow ¼" expansion gap on each side of the center mounting foot.
4. Apply a scant bead of construction adhesive to the center mounting foot of the molding and gently press molding into place.
5. Let adhesive cure according to directions.