

FITMENT KIT



SPEC SHEET

SHERCO

2016 & newer

Part Number
3500-0001-00

KIT INCLUDES

| Part Name | Qty. | Part Dimensions | Part Number |
|---------------------------|-------------|----------------------------------|--------------------|
| Upper Strut Reducers | 2 | 0.116 wide x 10mm hole. | 3521-1200-22 |
| Swing Arm Sleeve | 2 | 1.730 wide x 17.5mm hole. | 3521-3200-22 |
| Strut Rod Shaft | 1 | 7" long shaft. | 4320-0300-22 |
| Front Axle Sleeve | 1 | 20mm id Front Axle Sleeve | 3522-0100-22 |
| R - Side Swing Arm Spacer | 1 | 1.5" od x 57/64" id x .500" long | 3522-1000-22 |

SETUP SPECS

| SQUARE WASHER (new style) Serial #: 10240101+ | | ROUND WASHER (old style) Serial #: 10230001 - 10240100 | |
|----------------------------------------------------------------------------|------------|------------------------------------------------------------------|------------|
| Strut Rod Length: | 9 - 11/16" | Strut Rod Length: | 9 - 11/16" |
| Left-Side Frame Spec: | 0.318" | Left-Side Frame Spec: | 0.280" |
| Right-Side Frame Spec: | 0.288" | Right-Side Frame Spec: | 0.200" |
| NOTE: Use spacer on right side out 1.5" od x 57/64" id x .55" long. | | | |

SNOWBIKE KIT INSTALLATION INSTRUCTIONS:

To complete your install, you will need to visit the **MANUAL** section of the MTN.TOP website to download the following instructions, OR simply scan the QR codes below:



***Note:** If you picked up a kit from a dealer, they may have already prepared your snowbike kit for installation. If so, you can skip the OFF-BIKE, SET UP INSTRUCTIONS.