

FITMENT KIT



SPEC SHEET

<i>KTM, SX-F / XC-F</i>	2011 - 2022 (250 ^{cc} - 350 ^{cc} - 450 ^{cc} - 501 ^{cc})	<i>Part Number</i> 3501-0401-00
<i>HUSQVARNA, FC, FE, FX</i> <i>GASGAS, MC, EC, EX</i>	NOTES: Linkage suspended bikes only. Does <u>NOT</u> fit PDS suspended bikes.	

<u>KIT INCLUDES</u>			
<i>Part Name</i>	<i>Qty.</i>	<i>Part Dimensions</i>	<i>Part Number</i>
Upper Strut Reducers	2	0.156 wide x 10mm hole.	3521-0100-22
Swing Arm Sleeve	2	1.800 wide x 17mm hole.	3521-2000-22
Strut Rod Shaft	1	6" long shaft.	4320-0200-22

<u>SETUP SPECS</u>					
SQUARE WASHER (new style) Serial #: 10240101+			ROUND WASHER (old style) Serial #: 10230001 - 10240100		
	2016-2022	2011-2015		2016-2022	2011-2015
Strut Rod Length:	8 - 11/16"	9 - 1/8"	Strut Rod Length:	8 - 11/16"	9 - 1/8"
Left-Side Frame Spec:	0.378"		Left-Side Frame Spec:	0.340"	
Right-Side Frame Spec:	0.138"		Right-Side Frame Spec:	0.050"	

SNOWBIKE KIT INSTALLATION INSTRUCTIONS:

To complete your install, you will need to visit the **MANUAL** section of the MTN.TOP website to download the following instructions, OR simply scan the QR codes below:



***Note:** If you picked up a kit from a dealer, they may have already prepared your snowbike kit for installation. If so, you can skip the OFF-BIKE, SET UP INSTRUCTIONS.