

# FITMENT KIT



# SPEC SHEET

<b><i>KTM, SX-F / XC-F</i></b>	<b>2023 &amp; newer</b> (250 <sup>cc</sup> - 350 <sup>cc</sup> - 450 <sup>cc</sup> )	<b>Part Number</b> 3501-0402-00
<b>HUSQVARNA, FC, FE, FX</b> <b>GASGAS, MC, EC, EX</b>	<b>NOTES:</b> Linkage suspended bikes only. Does <u>NOT</u> fit PDS suspended bikes.	

<b><u>KIT INCLUDES</u></b>			
<b>Part Name</b>	<b>Qty.</b>	<b>Part Dimensions</b>	<b>Part Number</b>
Upper Strut Reducers	2	0.156 wide x 10mm hole.	3521-0100-22
Swing Arm Sleeve	2	1.800 wide x 17mm hole.	3521-2000-22
Strut Rod Shaft	1	5" long shaft.	4320-0100-22

<b><u>SETUP SPECS</u></b>			
<b>SQUARE WASHER (new style)</b> Serial #: 10240101+		<b>ROUND WASHER (old style)</b> Serial #: 10230001 - 10240100	
Strut Rod Length:	7- 7/8"	Strut Rod Length:	7- 7/8"
Left-Side Frame Spec:	0.378"	Left-Side Frame Spec:	0.340"
Right-Side Frame Spec:	0.138"	Right-Side Frame Spec:	0.050"

## **SNOWBIKE KIT INSTALLATION INSTRUCTIONS:**

To complete your install, you will need to visit the **MANUAL** section of the MTN.TOP website to download the following instructions, OR simply scan the QR codes below:



**\*Note:** If you picked up a kit from a dealer, they may have already prepared your snowbike kit for installation. If so, you can skip the OFF-BIKE, SET UP INSTRUCTIONS.