

FITMENT KIT



SPEC SHEET

<i>KTM, EXC-F / XCW-F</i>	<i>2009 & newer</i> (350 ^{cc} - 450 ^{cc} - 500 ^{cc} - 501 ^{cc} - 530 ^{cc})	<i>Part Number</i> 3501-0403-00
<i>PDS</i>	<i>NOTE: PDS suspended bikes only. Does <u>NOT</u> fit linkage suspended bikes.</i>	

<i>KIT INCLUDES</i>			
<i>Part Name</i>	<i>Qty.</i>	<i>Part Dimensions</i>	<i>Part Number</i>
Upper Strut Reducers	2	0.156 wide x 12mm hole.	3521-0200-22
Swing Arm Sleeve	2	1.800 wide x 17mm hole.	3521-2000-22
Strut Rod Shaft	1	7" long shaft.	4320-0300-22

<i>SETUP SPECS</i>			
SQUARE WASHER (new style) Serial #: 10240101+		ROUND WASHER (old style) Serial #: 10230001 - 10240100	
Strut Rod Length:	<i>NOTE: These specs are currently unavailable.</i>	Strut Rod Length:	<i>NOTE: These specs are currently unavailable.</i>
Left-Side Frame Spec:		Left-Side Frame Spec:	
Right-Side Frame Spec:		Right-Side Frame Spec:	

SNOWBIKE KIT INSTALLATION INSTRUCTIONS:

To complete your install, you will need to visit the **MANUAL** section of the MTN.TOP website to download the following instructions, OR simply scan the QR codes below:



***Note:** If you picked up a kit from a dealer, they may have already prepared your snowbike kit for installation. If so, you can skip the OFF-BIKE, SET UP INSTRUCTIONS.