

# FITMENT KIT



# SPEC SHEET

**YAMAHA**

**2006 & newer**  
(250<sup>cc</sup> 2-Stroke)

**Part Number**  
3502-0201-00

## KIT INCLUDES

<b>Part Name</b>	<b>Qty.</b>	<b>Part Dimensions</b>	<b>Part Number</b>
Upper Strut Reducers	2	0.278 wide x 10mm hole.	3522-2104-00
Swing Arm Sleeve	2	2.514 wide x 18mm hole.	3522-2125-00
Strut Rod Shaft	1	7" long shaft.	4322-2003-00
Front Axle Sleeve	1	20mm id Front Axle Sleeve	3522-2201-00

## SETUP SPECS

<b>SQUARE WASHER (new style)</b> Serial #: 10240101+		<b>ROUND WASHER (old style)</b> Serial #: 10230001 - 10240100	
Strut Rod Length:	<b>NOTE: These specs are currently unavailable.</b>	Strut Rod Length:	<b>NOTE: These specs are currently unavailable.</b>
Left-Side Frame Spec:		Left-Side Frame Spec:	
Right-Side Frame Spec:		Right-Side Frame Spec:	

## **SNOWBIKE KIT INSTALLATION INSTRUCTIONS:**

To complete your install, you will need to visit the **MANUAL** section of the MTN.TOP website to download the following instructions, OR simply scan the QR codes below:



**OFF-BIKE SETUP**



**TRACK KIT INTSTALL**



**SPINDLE INSTALL**

**\*Note:** If you picked up a kit from a dealer, they may have already prepared your snowbike kit for installation. If so, you can skip the OFF-BIKE, SET UP INSTRUCTIONS.