

# FITMENT KIT



# SPEC SHEET

<b>YAMAHA, YZ-FX</b>	<b>2014 &amp; newer</b> (250 <sup>cc</sup> - 450 <sup>cc</sup> )	<b>Part Number</b> 3502-0401-00
----------------------	---	------------------------------------

<b><u>KIT INCLUDES</u></b>			
<b>Part Name</b>	<b>Qty.</b>	<b>Part Dimensions</b>	<b>Part Number</b>
Upper Strut Reducers	2	0.278 wide x 10mm hole.	3521-0400-22
Swing Arm Sleeve	2	2.514 wide x 17mm hole.	3521-2400-22
Strut Rod Shaft	1	6" long shaft.	4320-0200-22

<b><u>SETUP SPECS</u></b>			
<b>SQUARE WASHER (new style)</b> Serial #: 10240101+		<b>ROUND WASHER (old style)</b> Serial #: 10230001 - 10240100	
Strut Rod Length:	8-7/16"	Strut Rod Length:	8-7/16"
Left-Side Frame Spec:	0.278"	Left-Side Frame Spec:	0.240"
Right-Side Frame Spec:	0.548"	Right-Side Frame Spec:	0.460"

## **SNOWBIKE KIT INSTALLATION INSTRUCTIONS:**

To complete your install, you will need to visit the **MANUAL** section of the MTN.TOP website to download the following instructions, OR simply scan the QR codes below:



**OFF-BIKE SETUP**



**TRACK KIT INTSTALL**



**SPINDLE INSTALL**

**\*Note:** If you picked up a kit from a dealer, they may have already prepared your snowbike kit for installation. If so, you can skip the OFF-BIKE, SET UP INSTRUCTIONS.