

### XFR FRAME BAG

- **P/N:** 3022-5107-00
- **FITS:** MTN.TOP XFR Snow bike kits
- **INCLUDES:** 1 bag, 3 plastic spacer/nuts, 3 plastic washers and mounting hardware.

#### INSTALLATION INSTRUCTIONS:

1. Remove the (2) bolts and nuts holding the tunnel top to the snowbike frame. You will be replacing them with new hardware that is included.
2. Install (2) of the new longer bolts in from the bottom through the tunnel top and frame. Secure them with the provided plastic spacer/nut. Tighten the bolts from the bottom side. Make sure that they are plenty tight so that the tunnel top does not vibrate on the frame. Using a ratchet handle with 4mm socket key and extension up through the holes in the track works the best for tightening them. The long bolts will protrude through the spacer/nut as a stud for the bag to mount to.
3. Install the final longer bolt to complete the 3<sup>rd</sup> front mount to the factory bracket on the frame using the same technique as on the rear (2) mounts in Step 2.
4. Place the bag onto the (3) studs. It might be a tight fit so you may need to wiggle it on. Make sure that the strap on the front of the bag is up and not trapped under the bag before tightening.
5. Place a plastic washer onto each stud from the inside of the bag. These washers will seal the holes from water getting in. Then, install a nylock nut on each, and tighten them up so that they are snug but not overly tight to the plastic washer.

*Note: On the front stud, it will be a little too long and will have some thread sticking up past the nut. If you like you can use the (2) leftover washers from the factory bolts to take up the extra thread. This will ensure that you do not have any sharp parts on the inside of the bag.*

