








# TMB BRAKES





## 1967-1969 1ST GEN CAMARO FRONT F1 BRAKE KIT (W/ALUMINUM HUB) (001-0233)








## Parts List

	<p>Revolution Rotors - 10.75 / 0.280 / 5 on 5.25"</p> <p>Part Number: 3-10753105525D</p>
	<p>F1 Caliper, 1.75" Diameter Piston, .500" Rotor</p> <p>Part Number: 002-0054SSP-1</p>
	<p>F1 Caliper, 1.75" Diameter Piston, .500" Rotor</p> <p>Part Number: 002-0054SSP-2</p>
	<p>F1 to 1st Gen Camaro Caliper Bracket</p> <p>Part Number: 16-0232-1</p>
	<p>F1 to 1st Gen Camaro Caliper Bracket</p> <p>Part Number: 16-0232-2</p>
	<p>F1 / DR-1 Replacement Pads (full set) - #1</p> <p>Part Number: 6-1019</p>



## Hub Parts List

	<p>Late GM Hub</p> <p>Part Number: 8-103</p>
	<p>Oil Seal</p> <p>Part Number: TC45X65X8</p>
	<p>Bearing Set</p> <p>Part Number: 011-A2</p>
	<p>Bearing Set</p> <p>Part Number: 011-A6</p>
	<p>1/2''-20 X 2'' Wheel Studs (10 Pack)</p> <p>Part Number: 11-9803</p>












## Caliper Mounting Hardware

	4	Bolt, 3/8-24 X 1
	4	Lock Washer, 3/8"
	4	Flat ww, 3/8"
	10	Steel Shim, .010TK, 3/8 ID, 5/8 OD
	10	Steel Shim, .031TK, 3/8 ID, 5/8 OD

## Rotor Mounting Hardware



	10	Bolt, 5/16-18 X 3/4"
	10	Flat Washer, 5/16"

## Caliper Bracket Mounting Hardware

	2	Flat Washer, 1/2"
	2	Nylock Nut, 1/2-13
	2	FHCS Bolt, 5/8-18 X 1.25"
	2	FHCS Bolt, 1/2-13 X 1.5"
	2	FHCS Bolt, 1/2-13 X 3 1/4"
	2	Spacer, .88" OD X .625 ID, .500"
	10	Steel Shim, .010TK, 5/8 ID, 1 OD
	10	Steel Shim, .031TK, 5/8 ID, 1 OD
	10	Steel Shim, .010TK, 1/2 ID, 3/4 OD
	10	Steel Shim, .031TK, 1/2 ID, 3/4 OD
	10	Steel Shim, .062TK, 3/8 ID, 5/8 OD

**Step 1:** Remove the existing brake components and ensure the spindle is clean and free of debris.

**Step 2:** Apply Red Loctite to the 1/2" -20 wheel studs and fasten them to the hub. Torque to 60 ft-lbs.



**Step 3:** Lay the hub face down and place the flat side of rotor on the hub.

**Step 4:** Apply Red Loctite to the 5/16-18 X 3/4" bolts, torque to 18 ft-lbs.  
(Important: Do not Loctite or torque bolts until proper fitment is achieved)



**Step 5:** Pack inner bearing with grease and insert into back side of hub, Install the 45X65X8 rear seal.



**Step 6:** For disc brake spindles place the aluminum .500" spacer over the top hole and place three .031" shims over the lower mounting hole. Next bolt on the caliper bracket using the 5/8-18 X 1.25" FHCS and torque to 80ft/lbs. Then install the 1/2-13 FHCS, washer, and nylock nut and torque to 60ft/lbs.

NOTE: Drum brake spindle applications will NOT use the upper aluminum spacer.



**Step 7:** Pack outer bearing and install in hub. Slide hub and rotor assembly onto the spindle and secure with the washer and castle nut.



**Step 8:** Slide the caliper over the rotor and mount it to the bracket. Snug the 3/8-24 bolts, lock washer, and washer. Check for proper radial and horizontal clearance between the rotor and the caliper.




**Step 9:** Remove the pad retainer bolt (if already inserted). Insert the brake pads from the top of the caliper and reinsert the pad retainer bolt. Hold the pads against the caliper housing. Spin the rotor assembly to check for contact between the rotor and brake pads. There should be no contact between the rotor and pads. Be sure to tighten the pad retainer bolt once pads are installed.



# More Info

**Caliper Direction:** Calipers are labeled -1 and -2 with bleeders and fittings mirrored of each other. These



**Acceptable Pad Thickness:** Any time pads are  $<.100$ " thickness, we advise replacing them.

**Rotor Replacement:** Our main concern is rotor flatness. This dictates the performance of the rotor. For rotor thickness concerns please reach out to us directly at (800) 878-9274 as rotor thickness varies on each rotor style

**Fluid:** We recommend using TBM Extreme 6 High Performance DOT 5.1 brake fluid on any and all TBM brakes. This fluid is compatible with Dot 3 and Dot 4 fluid without having to drain your fluid system if you are not able to get your hands on TBM brake fluid. DO NOT ever use DOT 5 brake fluid as it is silicone based and will cause the seals to swell, hindering brake performance and life.

**Bearing Grease:** If your TBM Brakes utilize a hub that uses greasable bearings, we suggest using any Pre-mium Moly style grease. Our brakes ship with standard Timken bearings which are able to be used with normal bearing grease. Using this grease will still promote our no drag benefits.

**Replacement Bearings:** We use standard readily available Timken Part Number bearings in our kits to make replacement and servicing easy. In the event you need replacement bearings, use the part numbers listed in the kit instructions for reorder.

**Loctite Hardware:** We recommend Red Loctite on any and all hardware used in brake applications. Please follow proper procedures in cleaning and drying hardware and surfaces before applying to ensure proper results.

**Flipping Rotors:** Our rotors are designed to be flipped either direction when mounting; they are non-di-rec-tional. Flipping the rotors allows you to utilize the offset either direction for properly centering/spacing the rotor and caliper package.

**Replacement Hardware:** Please note we only sell hardware as complete kits. The hardware kit number listed in the instructions above.



**Cleaning Brakes:** The unique color and finish on TBM Brakes is an Electroless Nickel process that is extremely durable. Cleaning electroless nickel parts is easiest by using household stainless steel appliance cleaner. Spray parts, let sit for 60 seconds, and wipe off. We recommend removing pads prior to using this cleaner and cleaning rotors off with brake cleaner after you've finished cleaning electroless nickel parts to avoid any chemicals that can adversely affect braking conditions.

**Caliper Maintenance:** Our calipers are engineered, designed, and built to be the most durable calipers on the market. We have customers with over 30 years of abuse on calipers with several reseals and rebuilds throughout. We recommend sending calipers used heavily in every 2 seasons for a cleaning, inspection, and rebuild process. During this time we pressure and leak check the calipers. Any caliper sitting more than 1 year with fluid should be sent in for reseal as seals can become compromised. Please contact us directly to arrange maintenance at (800) 878-9274.

**Rotor Maintenance:** Over time, pad transfer will build up unevenly on the rotor face. This can result in high spots on the rotor, excessive pad knock-back, inconsistent pedal feel, and/or a decrease in brake torque. It is good practice to routinely clean the pad swept face of the rotors with 80 grit on a dual-action sander or with one of our rotor hones. This can be done as part of a pre-race weekend routine, or something you keep an eye on and work into your mid-season routine. After cleaning the rotor face you will want to follow the bedding procedure to lay a new transfer layer of material down onto the rotor.

**Bedding Procedures:** When bedding a new set of pads and rotors you are looking to transfer an even layer of pad material onto the rotor. At the drag strip, this can be done by making 2-3 passes and getting on the brakes as you would on any other pass. Getting firmly on the brakes for a second or two to scrub-off speed then off them completely. Get back on them firmly to make the turn, then try your best to come to a stop on the return road without applying a lot of brake. With the rotors hot, coming to a complete stop with a heavy foot can result in high spotting the brake material on the rotors. If trying to bed new pads and rotors away from the racetrack, it is recommended to do so in a safe and controlled environment. Decelerate quickly 4-5 times from roughly 35-50 mph. Trying not to come to a complete stop. Then, decelerate quickly 4-5 times from 50-15 mph. Trying not to come to a complete stop. If the area permits, drive a 1/4 mile dragging the brakes slightly at safe speeds. Then drive an equal distance or more without getting on the brakes, giving the rotors time to cool before coming to a stop. From here, you should notice pad material starting to evenly lay across the pad swept face of the rotor.

**Proper Caliper Shimming:** Every TBM brake kit comes with several mil-spec shims. These are available to you for a couple of reasons:

- 1.** They can be used to shim the caliper off of the bracket or the bracket off of the spindle in order to get the rotor centered in the caliper. Getting the rotor perfectly centered in the caliper is desired but can be offset slightly inboard or outboard. Making sure the pads fall in the caliper freely and there is no caliper to rotor clearance issues is the most important.
- 2.** The next important use of the shims is to shim the caliper so it is perfectly parallel with the rotor. This may result in having more shims behind one of the fasteners to achieve this.
- 3.** With the potential tolerance stack up across all the components getting mounted to the spindle, it can be common to need to shim the caliper to make it parallel to the rotor. (What might be required on one side of the vehicle may differ on the opposing side.) \*This is a critical step. If a caliper is mounted off parallel, the pistons will bind under load, and will not be able to retract properly.

**Tip:** Once you have the calipers where you think they should be, bleed the brake system. Once bled, loosen the caliper mounting bolts so the caliper can "float". Apply pressure to the brake pedal and if the caliper moves/twists, that is where the caliper wants to be under load. It is making itself parallel with the rotor. Shim the caliper off of the mounts so it stays there and tighten everything back up.