

STAINLESS STEEL WALL BRACKET

Operating instructions

Please ensure that you use 3.5 x 25 mm (No.6 x1") flat head screws to secure the bracket to a surface.

It is recommended that you use a silicone boot when placing the thermometer in the wall bracket.

Not using a silicone boot with the bracket could cause the thermometer to be scratched or scuffed.

Product code:

AR005487