




ADS-5322

LS Sanden 508 A/C Relocation Bracket Kit

<u>Bolts</u>	<u>Nuts/Washers</u>	<u>Spacers</u>
2 4 3/8"	5 Nuts	2 2 1/8"
5 2"	12 Washers	5 1"
4 2 5/8"	1 M10	3 1/2"

Installation Steps

1. Install the brackets using the 2 4-3/8" bolts, 2 2-1/8" and 1" spacers to hold the bracket in place. Use the 1" spacers up against the head.
2. Use the 2" bolt and 1 spacer to bolt the bracket to the bottom bolt hole of the head.
3. Install 2 2-5/8" bolts and 1" spacers into the water pump.
4. Install the a/c compressor using 2" bolts and nuts. Use the spacers on the front ears of the compressor to help alignment for serpentine belt.
5. Install the belt tensioner with the M10 nut provided.



Must use Gates Tensioner #38114