

INSTALLATION INSTRUCTIONS

- Paste recommended for non-woven wallpapers (preferably ready-made)
- Paste roller or wallpaper brush
- Wallpaper ruler
- Stanley knife or wallpaper scissors
- Soft rag

Instructions

Ensure that the wall is smooth, dust-free and is an even colour. Most importantly: make sure that you stick up the first strip vertically. After that, you will notice that putting up our wallpaper is easy and fun. If you doubt that your wall or strip is vertical, then use a plumb line or spirit level.

- 1 Apply paste to the wall with the roller or brush. Do this over a width of about 10 cm more than the strip will cover.
- 2 Stick the strips next to each other, edge-to-edge. Use the soft rag to smooth the wallpaper and brush out any air bubbles. Push the edges down well with your thumb.
- 3 Cut or trim the wallpaper to size.
- 4 Check each strip for paste residue, and if there is any, remove it immediately with a damp cloth.