

LOCK'ER[®] DOWN



LD2034 Install
Video

SECURITY PRODUCTS INSTALLATION INSTRUCTIONS

LD2034/LD2034EX

[2011-2016 Ford Super Duty]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now, **DO NOT REMOVE** the factory mat at the bottom of the console.
3. Insert the **LID ASSEMBLY** into the console on its side and diagonally, with the long tab facing forward in the console, and the indent of the tab facing towards the bottom of the console compartment (see Image 1 for reference)
4. Adjust the lid assembly inside the console so that the lid assembly is held against the top of the console compartment (see Image 2 for reference)
5. While holding the lid assembly up against the top of the compartment, place the two side brackets (with the bottom lip facing inward) onto the sides of the lid assembly so that the factory holes fit over the bolt threads on the inside of the lid assembly.
 - a. Secure the side brackets loosely to the lid assembly using the **LOCK'ER DOWN PROVIDED** 13mm nuts.
6. Set the X bracket into the bottom of the console so that the factory holes in the X bracket fit over the PIM studs on the side brackets (2 studs to each side bracket)
 - a. Secure the X bracket on loosely by apply the **4 LOCK'ER DOWN PROVIDED** acorn nuts to each of the 4 studs.
7. Tighten the bolts and the acorn nuts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
8. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 13mm Socket bit and 8mm Socket Bit

Contents Included: **4** 13mm Bolts.

4 Acorn Nuts

