

LOCK'ER[®] DOWN

SECURITY PRODUCTS

INSTALLATION INSTRUCTIONS

LD1043EX

[2014-2021 Toyota Tundra (Half Size Console Safe)]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
3. Remove the front and rear **10MM** bolts from the right side of the console compartment.
4. Remove the padding from the bottom of the inside of the safe.
5. Set the safe into the center console.
 - a. To ensure that the safe is properly aligned in the compartment, make sure that the slotted holes at the base of the safe line up with the factory holes on the right side of the console compartment.
6. Using your 10mm fastening device, insert the **LOCK'ER DOWN PROVIDED 10MM BOLTS** into the factory holes at the bottom of the safe (these holes should line up with the factory screw holes at the bottom of the compartment)
 - a. There are two 10mm bolts provided by Lock'er Down, the **LONGER** of the two bolts goes in the hole in the rear, and the shorter goes in the hole in the front.
 - b. Places the washers around the bolts so that it is between the bolt and the safe before tightening the bolts down.
7. Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
8. Re-insert the padding that was removed from the safe before installation.
9. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 10mm Socket bit

Contents Included: **1** Long 10mm Bolts.

1 Short 10mm Bolt

2 Washers

