

LOCK'ER[®] DOWN

SECURITY PRODUCTS

INSTALLATION INSTRUCTIONS

LD2003

[2003-2006 Chevrolet Avalanche, Silverado, Suburban, and Tahoe/ GMC Yukon, Yukon XL, and Sierra]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now and remove the plastic tub inside the center console compartment.
3. Remove the **4** screws that hold the lid onto the center console compartment, as well as the **2** screws in at the rear of the console compartment.
4. Set the safe into the center console where the plastic tub used to be.
 - a. The holes on the top lip of the safe should line up with the **4** screw holes where the lid attaches to the console (see image for installation orientation)
5. Using a drill or screwdriver, apply the **4 LOCK'ER DOWN** screws to re-apply the lid to the center console.
 - a. When applying the screws, make sure that the lid for the console is placed over the safe, and the screws are put in such that this orientation is achievable.
6. Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
7. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **PHILLIPS HEAD SCREW DRIVER**

Contents Included: 4 Phillips Head Screws.

